

Batteries & Supercaps

Supporting Information

Gassing Behavior of High-Entropy Oxide Anode and Oxyfluoride Cathode Probed Using Differential Electrochemical Mass Spectrometry

Ben Breitung,* Qingsong Wang, Alexander Schiele, Đorđije Tripković, Abhishek Sarkar, Leonardo Velasco, Di Wang, Subramshu S. Bhattacharya, Horst Hahn, and Torsten Brezesinski* © 2020 The Authors. Published by Wiley-VCH Verlag GmbH & Co. KGaA. This is an open access article under the terms of the Creative Commons Attribution License, which permits use, distribution and reproduction in any medium, provided the original work is properly cited.

Table of Contents

Calculation of configurational entropy (Equation S1)

Cycling protocol (Table S1)

Long-term cycling performance (Figure S1)

4.8 V DEMS results (Figure S2)

4.6 V DEMS results (Figure S3)

Comparison of integrated amounts of evolved gases (Figure S4)

$$S_{\text{config}} = -R \left[\left(\sum_{i=1}^N x_i \ln x_i \right)_{\text{cation}} + \left(\sum_{j=1}^M x_j \ln x_j \right)_{\text{anion}} \right]$$

Equation S1. Calculation of configurational entropy (S_{config}), with x_i and x_j representing the molar fraction of cations and anions on the respective sublattice.

Table S1. Cycling protocol used for the electrochemical testing of the HEO anode material in LIB half-cells. 1/10th of the set current was used as the termination criterion in the CV steps.

Step	Reaction	Cutoff voltage	Rate	Mode	Number of cycles
1	Lithiation	10 mV	C/20	CC-CV	2
2	Delithiation	2500 mV	C/20	CC-CV	
3	Lithiation	10 mV	C/5	CC-CV	10
4	Delithiation	2500 mV	C/5	CC-CV	
5	Lithiation	10 mV	C/5	CC-CV	2
6	Delithiation	2500 mV	C/2	CC	
7	Lithiation	10 mV	C/5	CC-CV	2
8	Delithiation	2500 mV	C/5	CC	
9	Lithiation	10 mV	C/5	CC-CV	2
10	Delithiation	2500 mV	C/10	CC	
11	Lithiation	10 mV	C/5	CC-CV	20
12	Delithiation	2500 mV	C/5	CC-CV	
13	Continue with step no. 5				




Figure S1. Long-term cycling performance of the HEO anode material in a LIB half-cell at a C/5 rate in the voltage range of 10–2500 mV versus Li^+/Li . LP57 (blue) or 1 M LiPF_6 in FEC:EMC (red) was used as electrolyte. Note that the first two activation or formation cycles were performed at a C/20 rate.




Figure S2. Gassing behavior of the $\text{Li}(\text{HEO})\text{F}$ cathode material in a LIB half-cell using LP57 electrolyte at a C/10 rate in the voltage range of 2.0–4.8 V versus Li^+/Li . Voltage profiles (gray) for the first three cycles and the corresponding gas evolution of H_2 ($m/z = 2$, gold), O_2 ($m/z = 32$, blue) and CO_2 ($m/z = 44$, pink; and via integration of IR absorbance [$2315\text{--}2380\text{ cm}^{-1}$], purple) are shown. No significant amount of CO was detected.




Figure S3. Gassing behavior of the Li(HEO)F cathode material in a LIB half-cell using LP57 electrolyte at a C/10 rate in the voltage range of 2.0–4.6 V versus Li⁺/Li. Voltage profiles (gray) for the first three cycles and the corresponding gas evolution of O₂ ($m/z = 32$, blue) and CO₂ ($m/z = 44$, pink; and via integration of IR absorbance [2315–2380 cm⁻¹], purple) are shown. No significant amounts of H₂ and CO were detected.




Figure S4. Quantitative comparison of the results obtained from *in situ* pressure and DEMS measurements (integrated amounts of evolved gases).